

Burner Assembly...

- 1 - Air Gates
- 2 - Air Tub
- 3 - Bleed Valve
- 4 - Burner Fan & Casing
- 5 - Burner Motor
- 6 - Cad Cell (Not Shown)
- 7 - Cad Cell Relay Controls
- 8 - Electrodes (Spark)
- 9 - End Cone
- 10 - Flip-Up Peep Door
- 11 - Fuel Line Size Adapter (Brass)
- 12 - Fuel Pump
- 13 - Jet Line
- 14 - Motor Wiring
- 15 - Nozzle
- 16 - Nozzle Line (Internal)
- 17 - Reset Button
- 18 - Strainer
- 19 - Strainer Plug
- 20 - Transformer/Igniter

Covered by
Silver Service Plan

Gold Service Plan
Covers Silver Parts

